

NOVAPOINT 18.00

INSTALLATION GUIDE



Novapoint

www.novapoint.com

Note: Where this guide differs from the description in the guide included in the CD cover, it is the description in this guide that applies.

Contents

End user license agreement	3
Before you install	7
About the installation	7
Upgrade from earlier versions	7
System requirements	8
Novapoint Launcher	9
About Novapoint	9
Install Products	10
Licensing Novapoint	11
Novapoint GeoSuite Toolbox	12
Install Novapoint	13
Prepare for installation	13
Install Novapoint	13
Unattended installation	14
Locate files for Novapoint	15
Uninstall Novapoint	16
Supplementary installation programs	17
PDF reader	17
Novapoint GeoSuite Toolbox	17
PlaBas	17
References	18

End user license agreement

IMPORTANT-READ CAREFULLY: This Vianova Systems AS End-User License Agreement ("EULA") is a legal agreement between you (either an individual person or a single legal entity, who will be referred to in this EULA as "You") and Vianova Systems AS for the above-identified Vianova Systems AS software product that accompanies this EULA, including any associated media, printed materials and electronic documentation (the "Software Product"). The Software Product also includes any software updates, add-on components, stencils, templates, shapes, symbols, web services, documentation, training material, brochures and/or supplements that Vianova Systems AS may provide to You or make available to You, or that You obtain from the use of features or functionality of the Software Product, after the date you obtain your initial copy of the Software Product (whether by delivery of a CD or DVD or other media, permitting downloading from the Internet or a dedicated web site, or otherwise) to the extent that such items are not accompanied by a separate license agreement or terms of use. By installing, copying, downloading, accessing or otherwise using the Software Product, you agree to be bound by the terms of this EULA. If you do not agree to the terms of this EULA, do not install, access or use the Software Product; instead, you should return it to your place of purchase for a full refund.

SOFTWARE PRODUCT LICENSE

The Software Product and all its contents are protected by intellectual property laws and treaties. The Software Product is licensed, not sold.

1. GRANT OF LICENSE. This Section of the EULA describes Your general license rights to install and use the Software Product. It also describes a set of additional license rights. The license rights described in this Section are subject to all other terms and conditions of this EULA.

1.1 General License Grant to Install and Use Software Product. You may install and use one copy of the Software Product on a single computer, device, workstation, terminal, or other digital electronic or analog device ("Device"). You do not have the right to allow other people to access and use Your copy of the Software Product from Your Device unless You follow the restrictions described in the alternative license grant in the next paragraph. If You run a business or enterprise, You may install a second copy of the Software Product on a portable Device owned by You for the exclusive use of the person within Your business or enterprise who is the user of the primary copy of the Software Product, provided that such person only uses the second copy for business purposes, and provided that such installation and use otherwise comply with all the terms and conditions of this EULA.

1.2 Alternative License Grant for Storage/Network Use. As an alternative to the rights granted in the previous section, You may install a copy of the Software Product on a storage Device, such as a network server, and allow individuals within your business or enterprise to access and use the Software Product from other Devices over a private network, provided that you acquire and dedicate a license for the storage Device upon which the Software Product is installed and each separate Device from which the Software Product is accessed and used. This license does not give you a right to allow anyone to access or use the Software Product over the Internet. This license grant includes the right to exercise the additional license rights described in the following sections. A license for the Software Product may not be shared or used concurrently on different Devices.

1.3 Downgrades. Instead of installing and using the Software Product, you may install and use one copy of an earlier version of the Software Product on a single Device. Your use of such earlier version shall be governed by this EULA, and your rights to use such earlier version shall terminate when you install the Software Product.

1.4 Additional License Grant for Systems Administrators. You may allow system administrators within Your business or enterprise to access and use the Software Product for the sole purpose of assisting You with installing, configuring, and maintaining that copy of the Software Product. You must obtain separate licenses to the Software Product for systems administrators to use the Software Product as described in other sections of this EULA.

1.5 Dealer or demo versions. If the program version installed is a dealer- or demo version the dealer agreement and/or dealer kit agreement defines additional duties for such versions

1.6. Reservation of Rights. All rights not expressly granted are reserved by Vianova Systems AS.

2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS.

2.1 Academic Edition Software. If the Software Product is identified as "Academic Edition" or "AE," you must be a "Qualified Educational User" to use the Software Product. If you are not a Qualified Educational User, you have no rights under this EULA. To determine whether you are a Qualified Educational User, please contact the Vianova Systems AS, P.O. Box 434, N-1302 Sandvika, Norway, or the Vianova Systems AS subsidiary serving your country/region.

2.2 Mandatory Activation. You may not be able to exercise Your rights to the Software Product under this EULA unless You register your copy of the Software Product in the manner described during the launch sequence.

2.3 Copy Protection. The Software Product may include copy protection technology to prevent the unauthorized copying of the Software Product or may require original media for use of the Software

Product on the Device. It is illegal to make unauthorized copies of the Software Product or to circumvent any copy protection technology included in the Software Product.

2.4 Not for Resale Software. If the Software Product is labeled "Not For Resale" or "NFR," then, notwithstanding other sections of this EULA, your use of the Software Product is limited to use for demonstration, test, or evaluation purposes and you may not resell, or otherwise transfer for value, the Software Product.

2.5 Limitations on Reverse Engineering, Decompilation, and Disassembly. You may not reverse engineer, decompile, or disassemble the Software Product, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

2.6 Separation of Component Parts. The Software Product is licensed as a single product. Its component parts may not be separated for use on more than one Device unless expressly permitted by this EULA.

2.7 Trademarks. This EULA does not grant you any rights in connection with any trademarks or service marks of Vianova Systems AS.

2.8 No rental, leasing or commercial hosting. You may not rent, lease, lend or provide commercial hosting services to third parties with the Software Product.

2.9 Support Services. Vianova Systems AS may provide you with support services related to the Software Product ("Support Services"). Use of Support Services, if any, is governed by the Vianova Systems AS policies and programs described in the user manual, in "online" documentation, or in other Vianova Systems AS - provided materials. Any supplemental software code provided to you as part of the Support Services are considered part of the Software Product and subject to the terms and conditions of this EULA. You acknowledge and agree that Vianova Systems AS may use technical information you provide to Vianova Systems AS as part of the Support Services for its business purposes, including for product support and development. Vianova Systems AS will not utilize such technical information in a form that personally identifies you, if this is not agreed and permitted by you.

2.10 Termination. Without prejudice to any other rights, Vianova Systems AS may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the Software Product and return all of its component parts, HW locks etc. to Vianova Systems AS or its subsidiary serving your country/region.

3. UPGRADES.

3.1 Standard Software Product. If the Software Product is labeled as an upgrade, you must be properly licensed to use a product identified by Vianova Systems AS as being eligible for the upgrade in order to use the Software Product. A Software Product labeled as an upgrade replaces or supplements (and may disable) the product that formed the basis for your eligibility for the upgrade. You may use the resulting upgraded product only in accordance with the terms of this EULA. If the Software Product is an upgrade of a component of a package of software programs that you licensed as a single product, the Software Product may be used and transferred only as part of that single product package and may not be separated for use on more than one Device.

4. INTELLECTUAL PROPERTY RIGHTS. All title and intellectual property rights in and to the Software Product (including but not limited to any images, stencils, documentation, brochures, templates, shapes, symbols, photographs, animations, video, audio, music, text, and "applets" incorporated into the Software Product), the accompanying printed materials, and any copies of the Software Product are owned by Vianova Systems AS or its suppliers. All title and intellectual property rights in and to the content that is not contained in the Software Product, but may be accessed through use of the Software Product, is the property of the respective content owners and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants you no rights to use such content. If this Software Product contains documentation that is provided only in electronic form, you may print one copy of such electronic documentation. You may not copy the printed materials accompanying the Software Product.

5. BACKUP COPY. After installation of one copy of the Software Product pursuant to this EULA, you may keep the original media on which the Software Product was provided by Vianova Systems AS solely for backup or archival purposes. If the original media is required to use the Software Product on the Device, you may make one copy of the Software Product solely for backup or archival purposes. Except as expressly provided in this EULA, you may not otherwise make copies of the Software Product or the printed materials accompanying the Software Product.

6. EXPORT RESTRICTIONS. You acknowledge that the Software Product is of Norwegian origin. You agree to comply with all applicable international and national laws that apply to the Software Product, including the end-user, end-use and destination restrictions issued by Norwegian and other governments.

7. APPLICABLE LAW.

Norwegian law governs this Software Product. If this Software Product was acquired outside Norway, then local law may apply partly and prior to this agreement.

Should you have any questions concerning this EULA, or if you desire to contact Vianova Systems AS for any reason, please contact the Vianova Systems AS subsidiary serving your country/region, or write: Vianova Systems AS, PO Box 434, N-1302 Sandvika, Norway.

8. LIMITED WARRANTY

LIMITED WARRANTY FOR SOFTWARE PRODUCTS ACQUIRED IN Norway. Vianova Systems AS warrants that the SOFTWARE PRODUCT will perform substantially in accordance with the accompanying materials for a period of ninety (90) days from the date of receipt.

If an implied warranty or condition is created by your state/jurisdiction and federal or state/provincial law prohibits disclaimer of it, you also have an implied warranty or condition, BUT ONLY AS TO DEFECTS DISCOVERED DURING THE PERIOD OF THIS LIMITED WARRANTY (NINETY DAYS). AS TO ANY DEFECTS DISCOVERED AFTER THE NINETY (90) DAY PERIOD, THERE IS NO WARRANTY OR CONDITION OF ANY KIND. Some states/jurisdictions do not allow limitations on how long an implied warranty or condition lasts, so the above limitation may not apply to you.

Any supplements or updates to the SOFTWARE PRODUCT, including without limitation, any (if any) service packs or hot fixes provided to you after the expiration of the ninety (90) day Limited Warranty period are not covered by any warranty or condition, express, implied or statutory.

LIMITATION ON REMEDIES; NO CONSEQUENTIAL OR OTHER DAMAGES. Your exclusive remedy for any breach of this Limited Warranty is as set forth below. Except for any refund elected by Vianova Systems AS, YOU ARE NOT ENTITLED TO ANY DAMAGES, INCLUDING BUT NOT LIMITED TO CONSEQUENTIAL DAMAGES, if the SOFTWARE PRODUCT does not meet Vianova Systems AS' Limited Warranty, and, to the maximum extent allowed by applicable law, even if any remedy fails of its essential purpose. The terms of Section 10 below ("Exclusion of Incidental, Consequential and Certain Other Damages") are also incorporated into this Limited Warranty. Some states/jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Limited Warranty gives you specific legal rights. You may have others which vary from state/jurisdiction to state/jurisdiction.

YOUR EXCLUSIVE REMEDY. Vianova Systems AS' and its suppliers' entire liability and your exclusive remedy shall be, at Vianova Systems AS' option from time to time exercised subject to applicable law, (a) return of the price paid (if any) for the Software Product, or (b) repair or replacement of the Software Product, that does not meet this Limited Warranty and that is returned to Vianova Systems AS with a copy of your receipt. You will receive the remedy elected by Vianova Systems AS without charge, except that you are responsible for any expenses you may incur (e.g. cost of shipping the Software Product to Vianova Systems AS). This Limited Warranty is void if failure of the Software Product has resulted from accident, abuse, misapplication, abnormal use or a virus. Any replacement Software Product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer. Outside the Norway, neither these remedies nor any product support services offered by Vianova Systems AS are available without proof of purchase from an authorized international source. To exercise your remedy, contact: Vianova Systems AS, PO Box 434, N-1302 Sandvika, Norway, or the Vianova Systems AS subsidiary serving your country/region.

9. DISCLAIMER OF WARRANTIES. Vianova Systems AS AND ITS SUPPLIERS PROVIDE THE SOFTWARE PRODUCT AND SUPPORT SERVICES (IF ANY) *AS IS AND WITH ALL FAULTS*, AND HEREBY DISCLAIM ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, ANY (IF ANY) IMPLIED WARRANTIES, DUTIES OR CONDITIONS OF MERCHANTABILITY, OF FITNESS FOR A PARTICULAR PURPOSE, OF ACCURACY OR COMPLETENESS OF RESPONSES, OF RESULTS, OF WORKMANLIKE EFFORT, OF LACK OF VIRUSES, AND OF LACK OF NEGLIGENCE, ALL WITH REGARD TO THE SOFTWARE PRODUCT, AND THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES. ALSO, THERE IS NO WARRANTY OR CONDITION OF TITLE, QUIET ENJOYMENT, QUIET POSSESSION, CORRESPONDENCE TO DESCRIPTION OR NON-INFRINGEMENT WITH REGARD TO THE SOFTWARE PRODUCT.

10. EXCLUSION OF INCIDENTAL, CONSEQUENTIAL AND CERTAIN OTHER DAMAGES. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL Vianova Systems AS OR ITS SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS OR CONFIDENTIAL OR OTHER INFORMATION, FOR BUSINESS INTERRUPTION, FOR PERSONAL INJURY, FOR LOSS OF PRIVACY, FOR FAILURE TO MEET ANY DUTY INCLUDING OF GOOD FAITH OR OF REASONABLE CARE, FOR NEGLIGENCE, AND FOR ANY OTHER PECUNIARY OR OTHER LOSS WHATSOEVER) ARISING OUT OF OR IN ANY WAY RELATED TO THE USE OF OR INABILITY TO USE THE SOFTWARE PRODUCT, THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, OR OTHERWISE UNDER OR IN CONNECTION WITH ANY PROVISION OF THIS EULA, EVEN IN THE EVENT OF THE FAULT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, BREACH OF CONTRACT OR BREACH OF WARRANTY OF Vianova Systems AS OR ANY SUPPLIER, AND EVEN IF Vianova Systems AS OR ANY SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

11. LIMITATION OF LIABILITY AND REMEDIES. NOTWITHSTANDING ANY DAMAGES THAT YOU MIGHT INCUR FOR ANY REASON WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ALL DAMAGES REFERENCED ABOVE AND ALL DIRECT OR GENERAL DAMAGES), THE ENTIRE LIABILITY OF Vianova Systems AS AND ANY OF ITS SUPPLIERS UNDER ANY PROVISION OF THIS EULA AND YOUR EXCLUSIVE REMEDY FOR ALL OF THE FOREGOING (EXCEPT FOR ANY REMEDY OF REPAIR OR REPLACEMENT ELECTED BY Vianova Systems AS WITH RESPECT TO ANY BREACH OF THE LIMITED WARRANTY) SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU FOR THE SOFTWARE PRODUCT OR EURO 5.00. THE FOREGOING LIMITATIONS, EXCLUSIONS AND DISCLAIMERS (INCLUDING SECTIONS 8, 9 AND 10 ABOVE) SHALL APPLY TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, EVEN IF ANY REMEDY FAILS ITS ESSENTIAL PURPOSE.

12. ENTIRE AGREEMENT. This EULA (including any addendum or amendment to this EULA which is included with the Software Product) is the entire agreement between you and Vianova Systems AS relating to the Software Product and the support services (if any) and they supersede all prior or contemporaneous oral or written communications, proposals and representations with respect to the Software Product or any other

subject matter covered by this EULA. To the extent the terms of any Vianova Systems AS policies or programs for support services conflict with the terms of this EULA, the terms of this EULA shall control.

Before you install

About the installation

This guide covers single installation and network installation of Novapoint.

To run the installation programs, insert the *Novapoint DVD* into your computer's DVD drive. The *Novapoint Launcher* starts automatically. If not, run the file *setup.exe* on the DVD drive.

To run Novapoint, the following steps should be done:

1. Install Novapoint
2. Install License Hardware Lock and Driver *or* install Network License Manager
3. Retrieve and install the License Key

To be able to start your Novapoint application you need to have installed a license hardware lock or the Network License Manager on a license server, and you must have a license file. See *How to License Novapoint* for details.

Upgrade from earlier versions

With respect to installation, Novapoint 18.00 is a new product, not an upgraded variant of earlier versions. Thus it has to be installed from scratch, as an upgrade from earlier versions of Novapoint cannot be done.

Novapoint 18.00 can be installed side by side with earlier versions, but cannot run parallel to earlier versions.

System requirements

Before you install Novapoint on a stand-alone computer, make sure that your computer meets the minimum requirements. See the following table for hardware and software requirements.

Hardware	Requirement	Notes
Processor	Pentium III or later 1 Ghz (minimum) 2 Ghz (recommended)	
RAM	2 GB (recommended)	
Video	1024 x 768 VGA with True Color (minimum)	Requires a Windows-supported display adapter.
Hard disk	Full installation 1,5 GB Minimum installation 500MB	
Pointing device	Mouse, trackball or other device	
CD-ROM	Any speed (for installation only)	
USB port	USB 1.2	For license hardware lock
Optional hardware	OpenGL-compatible professional 3D graphics card Printer or plotter Digitizer Modem or access to an internet connection Network interface card	OpenGL card is required to run Novapoint Virtual Map. The OpenGL driver that comes with the 3D graphics card must have the following: <ul style="list-style-type: none"> • Full support of OpenGL version 1.1 or later. NVIDIA graphics drivers are recommended. • An OpenGL Installable Client Driver (ICD). The graphics card must have an ICD in its OpenGL driver software. The "miniGL" driver provided with some cards is not sufficient for use with Novapoint 18.
Operating System	32 bit editions: Windows XP Professional SP2 Windows Vista Business Windows Vista Enterprise Windows Vista Ultimate Windows 7 Professional Windows 7 Enterprise Windows 7 Ultimate	You must have Administrator permissions to install Novapoint Novapoint may also be run on other Windows platforms, although full functionality cannot be guaranteed.
Autodesk	AutoCAD 2010 AutoCAD Map 3D 2010 AutoCAD Civil 3D 2010	


Novapoint Launcher

The Novapoint Launcher has the following pages:

About Novapoint

This page has the following options:

- **Release Notes** – links to the Novapoint wiki pages where Release Notes are updated
- **Contact Info** – opens the document *Contact Info.pdf* stored on the DVD in the *Bin\Doc* folder



Install Products

This page has the following options:


- **View Novapoint Installation Guide** – opens this document, *Novapoint Installation Guide.pdf* stored in the *Bin\Doc* folder on the DVD
- **Install Novapoint** – starts the *InstallShield for Novapoint*
- **Install Novapoint GeoSuite Toolbox**
- **Install Adobe Reader 9.1** – starts the *InstallShield for Adobe Reader 9.1* (a tool for viewing files of PDF format)



Licensing Novapoint

This page has the following options:


- **How to License Novapoint** – opens the document *How to license Novapoint.pdf* stored in the *Bin\Doc* folder on the DVD
- **Install USB License Hardware Lock Driver** – starts the *USB License Hardware Lock Driver Installation*
- **Install Network License Manager** – installs the Network License Manager
- **FLEXIm End User Guide**– opens the document *FLEXIm End User Guide.pdf* stored in the *Bin\Doc* folder on the DVD



Novapoint GeoSuite Toolbox

This page has the following options:

- **Select AutoCAD version** – Select the AutoCAD version you are installing for
- **Select localization** – Select the localized version you want to install
- **Install Novapoint GeoSuite Toolbox** – Start the *InstallShield* for corresponding Novapoint GeoSuite Toolbox version.
Select AutoCAD 2010 and Swedish will install **Novapoint GeoSuite Toolbox R18.0 (Swedish)**



Install Novapoint

Prepare for installation

There are several preparatory steps you can take to ensure that your installation of Novapoint is successful.

1. Make sure you have administrator permissions to the local machine where Novapoint will be installed. You do not need to have domain administrator permissions.
2. Close all running applications.

Install Novapoint

To install Novapoint on a stand-alone computer

1. Click the *Install Novapoint* link on the *Install Products* page.
2. On the Welcome to the *InstallShield for Novapoint* page, click *Next*.
3. Review the Novapoint software license agreement. You must accept this agreement to complete the installation. To accept, click *I accept the terms in the license agreement*, and then click *Next*.
4. On the *Destination Folder* page, choose the default path for the installation, or click *Change* to specify a custom path. Click *Next*.
5. On the *Setup Type* page choose *Typical* to install the default Novapoint installation or choose *Custom* to select other Novapoint features:
 - Novapoint Program files
 - Novapoint Site Tool program files
6. On the *Ready to Install the Program* page, click *Install* to begin the installation. If you want to review or change any of your installation settings, click *Back*. Click *Cancel* to exit the wizard.
7. Wait until the installation is completed.
8. When the installation is completed, the *InstallShield Wizard Completed* is displayed.
9. If the computer have a connection to the internet, check *Yes, check for program updates (recommended)*.
10. Click *Finish* to close the *Novapoint InstallShield Wizard*.
11. Install a license for Novapoint. See *How to license Novapoint* on the *Licenseing Novapoint* page
12. Start Novapoint and select the AutoCAD and configuration to use.

Unattended installation

The GUI is disabled during unattended installation. In order to successfully install Novapoint it is necessary to provide the correct parameters. MSIEEXEC.EXE must be present in the path on each client computer. The installation requires administrator privileges on the client computer.

Syntax:

To install Novapoint using MSIEEXEC.EXE use the following syntax:

`MSIEEXEC /i "MSI file" INSTALLDIR="Path" ADDLOCAL=Feature ALLUSERS=1 /qb`

MSI file:

Full path and filename of the installation MSI file.

Example: X:\install\Novapoint 18.00.msi

INSTALLDIR:

Installation folder for Novapoint:

Example: INSTALLDIR="c:\Program Files\Vianova\Novapoint\18.00"

ADDLOCAL:

Specify the Windows Installer features to install. The Novapoint 18.00 setup includes features for both Novapoint and Novapoint Site Tool.

To install Complete Novapoint:

This is the default installation and there is no need to specify features. Do not use the ADDLOCAL option

To install Novapoint Site Tool only:

`ADDLOCAL = _NP_Required`

ALLUSERS

Install for all users:

`ALLUSERS=1`

Complete command line:

Install complete Novapoint:

`Msiexec /i X:\install\Novapoint 18.00.msi " INSTALLDIR="c:\Program Files\ViaNova\Novapoint\18.00" ALLUSERS=1 /qb`

Install Novapoint Site Tool:

`Msiexec /i X:\install\Novapoint 18.00.msi " INSTALLDIR="c:\Program Files\ViaNova\Novapoint\18.00" ADDLOCAL=_NP_Required ALLUSERS=1 /qb`

First time startup configuration

During first time startup of Novapoint 18.00 the user is prompted to specify the configuration to use with Novapoint 18.00.

The selection is stored in the Current User area in the registry:

[HKEY_CURRENT_USER\Software\Vianova\Novapoint\18.00\Kernel Services]

Current Config

Language

AutoCAD Registry Key

If you prefer to avoid the first time startup dialog to pop up, these values have to be set.

The content varies based on the AutoCAD version and Novapoint language.

Locate files for Novapoint

The file locations for program files and application data for Novapoint should be:

[Program Files Folder]\Vianova\Novapoint\xx.xx is the folder where Novapoint is installed, e.g. *C:\Program Files\Vianova\Novapoint\18.00*. The name of the folder is language dependent.

[Application Data Folder] is by default found under your user login name in the windows *Documents and Settings* folder, e.g. for the user login name USER; *C:\Documents and Settings\USER\Application Data*. The name of the folders are language dependent.

The directory structure beneath these folders is ... \ViaNova\Novapoint\xx.xx\<Country>\<Product> where

- xx.xx is the version number.
- <Country> is the directories for national variants of Novapoint.
- <Product> is the directories for each Novapoint product line.

Note: Windows has two Application Data folders. In addition to the one described above, there is another located at *Documents and Settings\USER\Local Settings\Application Data*. This folder should not be confused with the *[Application Data Folder]* described above.

Uninstall Novapoint

Always uninstall Novapoint using the uninstall feature in Add / Remove programs.
To uninstall Novapoint.

1. On the *Start* menu, click *Control Panel*.
2. For Windows XP. In the Control Panel, double-click *Add or Remove Programs*.
For Windows 7. In the Control Panel, double-click *Programs and Features*
3. In the *Add or Remove Programs* window, select *Novapoint.xx* (where xx is the version number) in the list, and then click *Remove* or *Uninstall*.
4. Follow the instructions.

Supplementary installation programs

PDF reader

A program for reading PDF files, Adobe Reader 9.1, can be installed from the *Install Products* page in the Novapoint Launcher.

Novapoint GeoSuite Toolbox

Novapoint GeoSuite Toolbox can be installed from the *Install Products* page in the Novapoint Launcher

PlaBas

The PlaBas plant database can be downloaded from www.novapoint.com.

References

Release Notes – Linked to from the *About Novapoint* page in the Launcher.

Novapoint Installation Guide – this document, stored on the DVD in the *Bin\Doc* folder, and linked to from the *Install Novapoint* page in the Launcher.

How to License Novapoint – stored on the DVD in the *Bin\Doc* folder, and linked to from the *Licensing Novapoint* page in the Launcher.

FLEXIm End User Guide – stored on the DVD in the *Bin\Doc* folder, and linked to from the *Licensing Novapoint* page in the Launcher.

Contact Info – stored on the DVD in the *Bin\Doc* folder, and linked to from the *About Novapoint* page in the Launcher.